Student Activity 14: Recording Tuff-Bot's Travels with a Camera



Let's take Tuff-Bot on some journeys and record its adventures with a camera! Your teacher will set up the camera for you and show you how to use it.

You can take still pictures (photos) or videos with the camera. You can even control the camera from afar with the wristband remote.

Press the gray button to start or stop a video recording. Press the red button to take a snapshot. Depending on the mode that the camera is in, you can also take a burst of photos or time lapse.





If you are controlling Tuff-Bot remotely using an app or the TacTile Code Reader, then you can do everything you need from a distance while Tuff-Bot explores places even you can't go.

Turn the camera on by pressing the Power button on the front. Place the mounted camera in the center hole of Tuff-Bot and start recording. Either use the wristband remote or press the Select button at the top of the camera. You will use the same button to turn off recording. Your teacher will help you see the videos or photos on the camera or on your computer. Have fun!